# 

.MERSON

## **IMPORTANT INFORMATION-MUST READ!**

©Hilmerson Safety: All rights reserved.

Temporary cover, designed for a single use application & MUST be removed prior to final cover plate installation.

CAUTION! **Electrical Hazard** Installing the cover incorrectly can cause a shock/electrocution hazard!

DO NOT INTERMIX COVERS! Specific covers are designed for specific fixtures.

Only use the Current Cover with the fixture for which it was designed!

# De-energize equipment before installing or removing covers.


Do not install or remove covers without authorization.

### HOW TO INSTALL:

Peel the adhesive and stick on. Put pressure on the adhesive areas.

#### **TO REMOVE:**

Simply grab the corner and remove. DO NOT USE TOOLS TO REMOVE!



STICK ON FACE OF OPEN OUTLET BOX

Questions on the approved and safe use of this product, contact Hilmerson Safety.® www.hilmersonsafety.com 952-224-9390

In no event shall Hilmerson Safety<sup>®</sup> be held liable for any direct, indirect, punitive, incidental, special consequential damages, to property or life, whatsoever arising out of, or connected with, the use or misuse of this product.

